Raytronics AG

Adhesive S1005 / S1006 (-55°C to +120°C)

TE Connectivity's S1005 thermosetting, low viscosity, two-part epoxy polyamide adhesive is supplied in polythene bottles and can be mixed by volume or weight. One bottle contains Part A, the pale yellow epoxy and the other bottle contains Part B, the polyamide hardener, which is amber.

TE Connectivity's S1006 thermosetting, flexible high viscosity, twopart epoxy polyamide adhesive is supplied in a bi-pack to eliminate mixing ratio errors. S1006 consists of an epoxy resin that is pale yellow and a polyamide hardener, which is amber.

S1005 / S1006 are excellent adhesives for many substrates including TE polyolefin tubings, moulded parts and adaptors, aluminium alloy standard connector end fittings and other metals including mild steel, brass and copper.



tyco	Raychem S1005/S1006		Raychem	
Electronics	Two-part epoxy adhesive			
Typical properties		Performance	Test methods	
Mechanical	Lap shear strength			
	Aluminium to aluminium	8KN	RK6611/RK6612 Clause 3.1.1	
	RNF-100 RNF-100	210N	RK6611/RK6612 Clause 3.1.2	
Chemical	Fluid resistance			
	Hydraulic fluid DTD 900/4881C	Excellent	Lap shear strength	
	Hydraulic fluid H-515	Excellent	after immersion in fluid for 24 hours at +23°C	
	Water	Excellent		
Specifications	S1005 RK6611	S1006 RK6612		

Raytronics AG

Wärmeschrumpftechnik

Installation

Surface preparation	The moulded part and cable jacket should be thoroughly degreased using a suitable solvent e.g. Isopropanol following the handling instructions supplied by the solvent supplier. After degreasing, the surfaces should be carefully abraded using a 100 grit abrasive cloth. Dust and other debris from abrasion should be wiped away with a dry tissue. Connectors or adaptors should only be degreased and not abraded.					
Mixing S1005	S1005 adhesive is supplied ir and B. Part A, the epoxy, is pall Part B, the polyamide hardener colour. Care should be taken no the bottle caps. Measure out of two Parts B by volume, or two three Parts B by weight, taking clean containers are used. Mix components thoroughly: any a the mixture will be eliminated shrinking process. After mixing uniform layer of adhesive to the	e yellow and r, is amber in ot to interchange one Part A and Parts A and g care that only the two air stirred into during the g, apply thin	Mixing S1006	S1006 is supplied with the epoxy resin and the hardener pre-weighed in two sachets separated by a dividing rail. To mix, slide off the dividing rail and knead the contents until a homogenous translucent pale yellow colour is obtained. After mixing, carefully cut open one corner of the bi-pack. Apply a thin, uniform layer of adhesive to the substrates. For best results adhesive mixed in the dual packs should be squeezed into a separate disposable dish and mixed with a spatula before application to substrates.		
Heating	Apply heat to the heat-shrinkable tubing / moulded part (refer to the Code of Practice No. 605 for full instructions) and when fully recovered, remove any excess adhesive using Isopropanol or similar solvent.					
Handling	For normal handling purposes, the adhesive will be sufficiently cured after 24 hours at room temperature. However, cure cycles above 60°C are recommended as these result in great bond strengths and the joint should not be severely flexed until one of the following cycles has been completed.					
	4 hours at 60°C	1 hour at 95°C	■ 2	24 minutes at 120°C		
Pot life	Once mixed S1005/S1006 has a pot life of up to 2 hours depending on the ambient temperatures.					
Shelf life	In excess of 12 months, when stored in the original unopened packaging at or below 23°C.					
Handling precautions	Irritant and dangerous for the environment while in its uncured state. Part B contains Triethylenetetramine. Irritating to eyes and skin. Risk of serious damage to eyes. May cause sensitisation by skin contact. Toxic to aquati organisms: may cause long-term adverse effects in the aquatic environment					
	In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, wash immediately with plenty of water and soap. Wear suitable gloves and eye/face protection. Avoid release to the environment. Refer to safety data sheet. These are available via www.raychem.com/corporate/partners.asp.					
Ordering	S1005: 1 kit contains 2 bottle S1006 Kit 1: 1 kit contains 2 S1006 Kit 2: 1 kit contains 4	sachets: 15g each	178ml Part Bipa 89ml Part Alar	-		

Tyco and Raychern are trademarks.